

Sail No:

# Access Breeze Sailing Dinghy

## Owner's Manual



Registered and Manufactured by:

**Access Dinghy Sailing Systems Pty Ltd**

ACN 56 079 318 031

## Index

	<b>Page:</b>
Introduction .. .. .	3
Declaration of Conformity .. .. .	4
Description of Craft: The Access Breeze: Specification .. .. .	5
General .. .. .	6
Maintenance & Repairs .. .. .	7
Safety Recommendations .. .. .	8
How to Rig a Breeze .. .. .	9
Handy Knots .. .. .	12
Guarantee .. .. .	13
Change of Ownership Form .. .. .	14

## Introduction

This manual has been compiled to help you to operate your craft with safety and pleasure. It contains details of the craft, the equipment supplied or fitted, its systems, and information on its operation and maintenance. Please read it carefully, and familiarise yourself with the craft before using it.

If this is your first craft, or you are changing to a type of craft you are not familiar with, for your own comfort and safety, please ensure that you obtain handling and operating experience before assuming command of the craft. Your dealer or national sailing federation or yacht club will be pleased to advise you of local sailing schools or competent instructors.

**Please keep this manual in a safe place, and hand it over to the new owner when you sell the craft.**

## Personal Floatation Devices (PFD's)

There are many types and variety of buoyancy aids available, manufactured to different sets of standards. The PFD is a personal item of safety equipment, designed specifically to assist in preserving a person's life when in the water. Some PFD's provides buoyancy to help you float with your head above the water.

**All sailors and volunteers should wear a PFD at all times whilst on, or near water.**

PFD's are subject to normal wear and tear. Each one should be checked regularly and if in doubt about its serviceability it should be replaced. If they become wet from salt water they should be hosed down with fresh water and allowed to dry.

### **PFD's and Children**

A properly designed PFD of the correct size will keep a child's mouth and nose clear of the water. A child should be taught how to put on a device and should be allowed to try it out in the water. It is important that the child feels comfortable and knows what the PFD is for and how it functions.

## Safety Precautions

If sailed with care, this boat is unlikely to capsize in normal use, provided that the sail area is adjusted to suit the prevailing conditions and the main sheet is not belayed. Whilst Access Dinghies have inherent design features ensuring maximum stability thereby reducing the chance of capsize, it should be remembered that these are small sailing dinghies and under certain weather, water and sailing conditions sensible precautions should be taken :

- Always reef the sails according to the weather conditions.
- Always have a manned safety boat in the sailing area.
- Always cancel sailing activities if inclement weather conditions dictate.
- Always lock centreboard in position with long centreboard locking pin provided.

## Capsize and Man Overboard

Re-boarding after man overboard. In the event of man overboard, use keel handle as a handhold. Board over the aft port or starboard sides.

## Towing

The strong point for towing is the bow eye. Attach the tow line to the bow eye with a bowline.

**The safety of the sailors should come first under all circumstances.**

# Declaration

**Model:**

**BREEZE**

**Hull Identification No:**

**Sail No:**

**Design Category D: “Sheltered Waters”**

Craft designed for voyages on small lakes, rivers or canals where conditions up to and including wind force 4 and significant wave heights up to and including 0.5mtr may be experienced.

**Capacity:**

Maximum number of people: 2  
 Maximum weight of Solo sailor–100 kg  
 Maximum weight of Tandem sailors - 120 kg.

Built by:  
 Access Dinghy Sailing Systems Pty Ltd  
 2/7 Bungaleen Court  
 Dandenong, Victoria 3175  
 Australia  
 Ph: 61 3 9768 3101 Fax: 61 3 9768 3103  
 Email: info@accessdinghy.org

Using the moulds, parts,  
 and measurements  
 authenticated by  
 Access Dinghy Sailing Systems Pty Ltd

REF	ESSENTIAL REQUIREMENTS	STANDARD USED
<b>2</b>	<b>General Requirements</b>	
2.1	Hull Identification No (HIN)	ISO10087.95E (attached to craft)
2.2	Builders Plate	ISO14945:2004 (attached to craft)
2.4	Owner’s Manual	ISO10240:1996 (attached)
<b>3</b>	<b>Integrity and Structural Requirements</b>	
3.1	Structure	ISO12215-1:2000 (as per Access Dinghy Sailing Systems Production Manual)
3.2	Stability and freeboard	ISO12217-3:2002
3.3	Buoyancy and flotation	ISO12217-3:2002
3.4	Manufacturers recommended load	ISO14946:2001 (as shown on Builders Plate)
3.5	Towing	ISO15084:2003
<b>5</b>	<b>Steering Systems</b>	
5.4.1	General Steering System	ISO8847:2004 (manual joystick)

Signed: .....

Date: .....

Chris Mitchell, Managing Director  
 Access Dinghy Sailing Systems Pty Ltd

## Description of Craft The Access Breeze

### Specification

<b>Length</b>	2.4 mtrs.
<b>Bam</b>	1.25 mtrs.
<b>Draft</b>	0.75 mtr.
<b>Weight</b>	70 kg (including 20 kg in the keel). Maximum number of people: 1adult, or 1 adult and 1 child, or 2 children. Maximum weight sailed solo - 100 kg. Maximum weight sailed tandem - 120 kg
<b>Sail Plan</b>	Cat rig
<b>Sail Area</b>	Mainsail 3.8 sq. mtrs (unbattened and reefable to 0.5 sq. mtr).
<b>Mast</b>	Main Mast (unstayed 4.2 mtr. Incorporating reefing drum in foot).
<b>Hull</b>	Indestructible rotomoulded construction with a stainless steel rubbing strip under the skeg to protect the hull from damage. Positive buoyancy. Heavily rockered for easy manoeuvrability. Seating design keeps helm weight low, plus weighted centre board makes the boat very stable and difficult to capsize.
<b>Seating</b>	Comfy self-draining seat
<b>Controls</b>	Steered by manual joystick. Mainsail is reefed and unreefed by rotating the mast.

## General

The boat has an engraved plate fitted on the starboard side of forward cockpit, showing the manufacturer, boat design category, maximum person capacity, maximum additional load and the CE Mark. **The parameters shown on this plate should not be exceeded.**

Steering is by a manual joystick located between the helm's legs, moving it to the left to go left and to the right to go right.

The sail area can be reduced or increased whilst under way using a reef furling system operated by hauling on a single continuous line.

### Included with your Access Breeze is:

- |                          |                            |
|--------------------------|----------------------------|
| 1. Breeze Sailing Dinghy | 8. Centreboard locking pin |
| 2. Mast                  | 9. Bobbin                  |
| 3. Boom                  | 10. Sail                   |
| 4. Centreboard           | 11. Mainsheet              |
| 5. Rudder                | 12. Outhaul                |
| 6. Rubber Box            | 13. Traveller              |
| 7. Paynter               | 14. Joystick               |

## **Maintenance**

It is recommended that the boat is covered when not in use to prevent UV and other weather damage. A specially designed cover is available from Access Dinghy Sailing Systems for this purpose.

If sails are to be left furled on the boat when not in use it is recommended that these are covered using a protective sail sock to prevent UV and other weather damage. These are available Access Dinghy Sailing Systems.

Do not let water remain in the boat when not in use. This can accelerate the deterioration of running rigging.

## **Repairs**

Contact Access Dinghy Sailing Systems, who will provide the best advice, along with adapted parts or materials for the repairs you can carry out yourselves. Major repairs should preferably be carried out by professionals.

## **Safety Recommendations**

Access Dinghies are designed with a hull form and other features which combine to give considerable stability. There is a simple set of rules which we must follow to continue our excellent safety record and prevent any accidents. The stability of the Access Dinghies are reliant upon the following factors.

### **Centreboards**

It is most important that the keel be fully down when sailing. The hole one third down the keel is there purely to facilitate sailing off a beach, and under no circumstances should people with disabilities be allowed to sail around with the keel held in this position. There is provision to lock the keel fully down so as even in a “knock down” it remains in place.

### **Seating**

Because the placement of sailor’s weight affects stability it is important that people remain seated low in the boat.

### **Reefing**

Being a displacement type hull extra sail area in strong winds does not mean more speed, all it does is push the bow too far into the water and make it more difficult to handle. In a breeze it is therefore recommended always to reef to suit the stronger gusts.

### **Towing**

If an Access dinghy needs to be towed on the water by another boat, it is safer and easier to tie the dinghy close along side and remove the rudder blade so that it cannot be “steered” in the wrong direction.

### **Transferring**




A pontoon system which enables safe, keel down transfer of sailors to and from the dinghy is available. Using this avoids off the beach keel handling and transferring problems. It ensures that keels remain down throughout transferring.

### **Discriminatory Keel and Reefing Adjustments**

For safety reasons people with disabilities need the keel down and because many are unable to raise and lower the keel to improve sailing performance and also unable to adjust the size of the sail by reefing, it is discriminatory to allow anyone to make these adjustments during a race.



# How to Rig a Breeze



- **PUTTING THE SAIL ON THE MAST**

1. The foot (bottom) of the mast has a hole in the moulding.
2. Place the top of the mast into the sleeve of the sail and push the mast right to the top of the sail.
3. The bobbin is placed at the bottom of the sail, with the large rim upwards.
4. Tie the sail onto the bobbin with a reef knot.



- **STEPPING THE MAST**

5. Loosen the knob under the console on the reefing drum
6. Carefully step the mast making sure the foot is firmly over the pin on the step.
7. With the sail full, tighten the knob to lock the reefing drum onto the mast.




- **FITTING THE BOOM**

The boom should be kept tidy with no loose ends trailing.



8. Untie and sort out the two ropes.
9. Position the boat facing into the wind.
10. Push the rowlock at the front end of the boom onto the bobbin.
11. Take the outhaul which runs along the boom and shackle it onto the corner of the sail (called the clew).
12. Pull the sail out to the boom end by pulling the outhaul tail and cleat it at the front end of the boom.
13. Now sort out the other rope, (called the sheet), and shackle it onto the rope traveller which runs across at the stern of the boat.
14. The other end of the sheet passes through the sheave on the mast support. Feed it through so you can work it from the seat.
15. Tie a figure of 8 knot to act as a stopper knot at the end of the sheet..



- **REEFING** : shortening sail area

16. Rotate the mast by hand to reduce sail area

17. You can put one complete turn of sail around the mast without adjusting the outhaul.

18. To reef further the outhaul needs to be released to allow the sail to travel forward along the boom.

19. When unreefing, unroll the sail, then adjust the outhaul and re-clip on boom.

20. The idea is not to flatten the sail along the boom as it should have enough slack to form a gentle curve.




- **THE STEERING**

21. Make sure the steering lines pass under the joystick correctly.

22. Fit the rudder box, making sure the rope traveller is above the tiller.

23. Remove the spring clip and pass the clevis pin up through the hole at the end of the tiller. Re-insert the clip.



24. Fit the alloy joystick extension.

- **LAUNCHING**

25. Pass the bow line (called a paynter) through the hole at the bow and fasten it with a bowline. (a knot which is always easy to untie). See instructions below.

26. Use the centreboard pin to hold the centreboard up when moving the boat around onshore.

27. Pin the centreboard in the half way position if you need to move the boat around in shallow water.

28. DO NOT ALLOW ANYONE TO SAIL WITHOUT THE CENTREBOARD FULLY DOWN OR THEY MAY CAPSIZE.

29. Use the centreboard pin to lock the centreboard down.—Insert the centreboard pin through the deadeye on the console and into the centreboard handle. Push the pin right in as far as it will go.



## Handy Knots

**BOWLINE**— The "King of Knots" - never jams or slips when tied properly.

1. Make overhand loop with the end held toward you, then pass end through loop.
2. Now pass end up behind the standing part, then down through loop again.
3. Draw up tight.



**FIGURE 8 KNOT** — Keeps the end of a rope from running out of a tackle or pulley.

1. Make underhand loop, bringing end around and over the standing part.
2. Pass end under, then up through the loop.
3. Draw up tight.



## Guarantee

If you need any help to resolve any problems with the boat, contact:

Access Dinghy Sailing Systems Pty Ltd  
2/7 Bungaleen Court  
Dandenong Victoria 3175  
Australia  
Ph: 61 3 9768 3101 Fax: 61 3 9768 3103  
Email: info@accessdinghy.org

### Terms of Guarantee

- 1 This guarantee is valid for a period of 12 months from the date of purchase from Access Dinghy Sailing Systems.
- 2 If any part or parts of the boat, including the rigging and fittings, is proved to be defective by reason of faulty design, workmanship or materials, we undertake to repair or replace the same free of charge, upon the following conditions:
  - (a) This guarantee applies only to the original boat and fittings, and not to any subsequent alterations, repairs or renewals.
  - (b) That, if at any time during the guarantee period, any parts are altered or repaired by any person not authorised by us, then this guarantee will immediately cease and become void concerning that part, or any other part affected by the work.
  - (c) That our decision on all questions relating to any defect shall be conclusive.
  - (d) That any part which has been replaced shall become our property.
  - (e) This guarantee specifically excludes damage resulting from external impact.

None of the terms of this guarantee effect your statutory rights.

Name: .....  
Address: .....  
Owner of Access Dinghy .....  
Sail No: .....  
HIN No: .....

is covered by the guarantee conditions displayed (above) in this Owner's Manual, delivered with this craft.

This guarantee begins ..... (date)

Signature for Access Dinghy Sailing Systems

.....

## Change of Ownership

Please ensure this Owner's Manual is handed to the new owner as it contains safety information that is of great importance to the new owner and is essential to compliance with the EU Recreational Craft Directive.

The Access Dinghy Sailing Association is hoping to keep a continuous register of all Access Dinghies. Your boat has been registered with them under your name and address. In order to enable us to keep this register up to date it would be very helpful if you could inform us of any change of ownership.

The form below is provided for you to photocopy and use to give us this information if you sell the boat.

**Please photocopy or copy:  
Do not cut this form out of the manual.**

**Change of Ownership Form**

Model:

Sail No:

Hull Identification No:

**New Owner:**

Name: .....

Address .....

.....

.....

.....

Phone No: .....

Please send completed copy of this form to:  
Access Dinghy Sailing Systems Pty Ltd  
2/7 Bungaleen Street  
Dandenong Vic 3175  
Australia